

WARRANTY

- Equipment is guaranteed for 12 months from date of purchase.
- The warranty is valid against original defects, whether material or manufacturing.
- Whenever an anomaly is found in the equipment, it should be returned as soon as possible, enclosing the purchase document.
- In the event of a warranty claim, damaged parts will be repaired or replaced at the manufacturer's discretion. In the event of replacement, the damaged parts shall become the property of the supplier.
- Any and all faults resulting from poor installation or use/handling of the equipment are excluded from the scope of the warranty.
- The equipment will lose its guarantee whenever any alteration/modification or even repair carried out by the user is identified.

DIRECTIVE 2002/96/CE



- This symbol means that the product must be collected separately at the end of its life cycle. Do not dispose of it in municipal waste bins as normal household waste.

SYMBOL



- This product is manufactured in compliance with the Low Voltage Equipment Directive 2006/95/EC.

PNH - PROFESSIONAL FURNITURE&INNOVATION
RUA DO ALTO - VALE DO GROU – APARTADO 86
3750 - 064 AGUADA DE CIMA
TEL. +351 234 690 190 FAX. +351 234 624 044
comercial@bypnh.pt www.bypnh.pt

Instruction Manual

Milk Thermos

P - N - H P R O F E S S I O N A L
F U R N I T U R E
& I N N O V A T I O N

GENERAL FEATURES

- General stainless steel construction;
- Stainless steel resistance;
- Temperature thermostat 0-85°C with mirror and black silk screened knob;
- Orange indicator light signaling temperature;
- Green signal light indicating the current;
- Stainless steel milk container with handle in bakelite;
- Stainless steel water tank;
- Power cable with plug;
- Feet;
- Tap for milk outlet;
- Stainless steel trimmer;

TABLE OF FEATURES

Model	Product Dimensions WxDxH (mm)	Gross Weight (Kg)	Net Weight (Kg)	Capacity. of Pots (Lts)	Dim. of Pots HxDiam. (mm)	Power (W)	Volt (V/Hz)	Pack size WxDxH (mm)
5L	545x280x310	8,730	8	Milk pot 5L Water pot 3.5L	Milk pot 190x210 Water pot 215x240	1200	230/50	545x360x340
10L	575x325x350	12,830	12	Milk pot 10L Water pot 7L	Milk pot 265x245 Water pot 291x280	1200	230/50	555x370x380
5L+5L	545x561x310	17,470	16	Milk pot (2x) 5L Water pot (2x) 3.5L	Milk pot (2x) 190x210 Water pot (2x) 215x240	2x1200	230/50	550x590x350

INSTRUCTIONS FOR USE

- Before using the appliance you must remove all the protective plastic from around the appliance and clean the glue particles with non-abrasive products so as not to damage the appliance.
- When choosing where to place the appliance, you should ensure that it is level and that its surface is made of non-combustible material. The appliance should also be kept away from walls and other materials which may crumble or catch fire when heated..
- Before connecting the appliance to the mains supply, make sure that the voltage shown on the rating plate corresponds to the mains voltage and check that the socket is capable of supporting the current of the appliance..
- After the previous checks, you can use the appliance by connecting the power cable to the mains and turning the temperature knob to the desired value.

MAINTENANCE AND CLEANING

- When cleaning the appliance, make sure the power cord is disconnected from the mains and that the appliance is completely cool.
- When cleaning the appliance, do not use water jets as there is a risk of electrical damage.
- Pans can be immersed in water for more effective cleaning.
- Note that the power supply cable must not come into contact with heating elements or other hot parts. If it is damaged, do not use it; replace it with a new one, which should be requested from the manufacturer.

SPECIAL SAFETY RULES

- When using the appliance, do not place cloths or other objects on it that could be damaged or cause any hazard.
- If you need to move the appliance to another location, do so when it is completely cool. If the appliance has to be moved while it is hot, use suitable gloves.
- In order to prevent the water in the thermos milk container from running out, check the water level regularly by lifting the lid of the milk container.
- Do not allow children to approach the appliance while it is hot.

Note: Do not connect the appliance to the mains without first covering the heating element with a liquid substance.